







因篇幅所限,本流电图中气动图不再细画,每台气动图表示方法均如下图所示.



3.



自 LPG 罐
3387
45-02-05-002

61-8"-LPG-02-389(C,30)

自 LPG 罐
3387
45-02-05-002

61-12"-LPG-03-389(C,30)

LPG 入罐
3387
45-02-05-002

LPG 特罐
33
45-02-05-002

61-6"-LPG-06-389

